

Accessories for current transformers

Snap-on brackets, plastic version (rigid)

for mounting the current transformer on standard top hat rail TH 35 mm (DIN EN 60715)



Variants

| Form | for CT type | |
|-----------|--|---|
| A (30 mm) | RSWR 21, SWR3010, SWR 4010, SWR-L 4010, SWR-S 5010, SWR 5010 SWR-S 6010, SWR 6010, SWR 6040, SWR 8010, SWR 8030 | X |
| B (35 mm) | RSWR 28, SWR-L 3010, SWR-K 4010 | X |
| C (49 mm) | SWR-S 3010, SWR-S 4010 | X |
| E (SWUR) | SWUR 18, SWUR 28, SWUR 42 | X |

Snap-on mounting base, metal version (rotatable)

for mounting the current transformer on standard top hat rail TH 35 mm (DIN EN 60715)



Variants

| Form | for CT type | |
|------------|------------------------|---|
| D1 (35 mm) | SWR-L 3010, SWR-K 4010 | X |
| D2 (49 mm) | SWR-S 3010, SWR-S 4010 | X |

Isolating caps

for protection of primary busbar mounting screws



Variants

| Form | for all types | |
|------|---------------|---|
| P | alle Typen | X |

More accessories

More accessories available on request e.g.:

- Copper tubes for use with Tube-unit CT's
- Copper busbars for use with Plug-in CT's

Spare parts

Spare parts on request:

- Busbar fixing brackets
- Busbar mounting screws
- Foot fastening brackets
- Secondary terminal covers
- Click-off hinges for split-core CT's